

Switched PDU

User Manual

Table of Contents

1. Introduction	1
2. PDU Package	3
3. Function	4
4. Installation.....	5
5. Web Interface.....	7

1. Introduction

CAUTION: This unit is intended for indoor use only. Do not install near water or expose this unit to moisture. To prevent heat buildup, do not coil the power cord when in use. Do not use extension cords. Do not attempt to make any internal changes to the power source. Do not attempt to modify any portion or component.

CAUTION: Do not user power generator as input power source of PDU.

CAUTION: High-voltage surges and spikes can damage this equipment. To protect from such power surges and spikes, this unit must have a good earth ground or good power surge protection.

CAUTION: Do not exceed the AC current rating for the selected model.

CAUTION: In order to be absolutely removed from the power supply, the power cord must be unplugged from the power source.

CAUTION: This PDU contains LETHAL VOLTAGES. All repairs and service should be performed by AUTHORIZED SERVICE PERSONNEL ONLY. There are NO USER SERVICEABLE PARTS inside the PDU. The installation of options, routine maintenance, and service of this product must be performed by individuals who are knowledgeable about the procedures, precautions, and hazards associated with AC power products.

The PDU is an Internet ready device designed and is equipped with an intelligent current-meter (True RMS) that will indicate the total power consumption of a power strip.

The PDU offers an easy set up and user-friendly communication software. This software provides the function that assistant manager to remotely monitor the multiple PDU power consumption to realize the total current power consumption and utilization for the enterprises.

Features:

- Built-in web server, manager can real time to monitoring the current consumption of the power strip.
- Build-in true RMS current meter.
- Setup easily, meter can read the IP address directly.
- Provide audible alarm when the power consumption over the threshold of warning and overload.
- Send the email and traps when the power consumption exceed the trigger value of warning or overload to the PDU.
- Provide utility, it can monitor a large mount of PDU at the same time.
- Support the SNMP and provide MIB for the PDU to be monitored by NMS.

- Provide power protection by the circuit breaker.
- Real time to control outlets of PDU.
- Indicate outlets status with LED.
- Support power on sequence.


2. PDU Package

The standard PDU package contains a Power Distribution Unit with supporting hardware and software. The components of the package are:

- Power Distribution Unit.
- Rack mount Brackets.
- CD-ROM, it contains:
- User Manual.
- PDU Software.
- MIB: Management Information Base for Network.
- Adobe Acrobat Reader.

3. Function

Interface



Functions	Description
Ethernet	RJ45 port for network communication port.
Audible Alarm	Warning- 1 beep in 1 second. Overload- 3 beeps in 1 second. Note: The audible alarm will keep beeping until the current gets back to normal and the current is lower than the threshold to 0.5 amps.
Function Button	<ul style="list-style-type: none">● Press and release to turn off the warning beeping. The overload beeping can not be cancelled.● Press and hold the key after 2 beeping; it can let the meter to show up the IP address● Press and hold the key after 4 beeping; it can change the way to get IP by DHCP or fixed IP.● Press and hold the key after 6 beeping; it can reset PDU back to default setting.
Meter	3 digits to display current and IP Address.
LED Indicator	DHCP (Green): Light on means PDU gets IP address by DHCP. PDU (Green): Indicate each output power status.
Circuit Breaker	Overload power protection.


4. Installation

This section will provide a quick instruction to install the PDU.

Rack Mount Instructions

- A) Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature specified by the manufacturer.
- B) Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.
- C) Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
- D) Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on over current protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
- E) Reliable Earthing - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips)."

Diagram



Hardware

1. Install mounting brackets.
2. The PDU comes with brackets for mounting in a rack. To mount the PDU into a rack performs the following procedure:
3. Attach the mounting brackets to the unit, using the four retaining screws provided for each of the brackets.
4. Choose a location for the brackets.
5. Align the mounting holes of brackets with the notched hole on the vertical rail and attach with the retaining screws.
6. Connect input and output power.
7. Connect Ethernet cable to the PDU.
8. Switch on the PDU.

Note 1:

The default setting for the way to get IP address is DHCP. If PDU can not get the IP from DHCP server, the IP address will stay at 192.168.0.216

Note 2:

TO SETUP THE NETWORK SYSTEM FOR PDU, STRONGLY RECOMMEND TO BUILD UP THE POWER MONITORING NETWORK SYSTEM ISOLATED WITH THE OTHERS, IN ORDER TO KEEP THE STABILITY OF GETTING POWER INFORMATION AND SYSTEM OPERATION.

5. Web Interface

Login:

Input the PDU IP address in web browser.


Default ID is **snmp**.

Password is **1234**.



Information: PDU

Display total PDU power consumption.




The screenshot shows a web-based interface for a PDU. At the top, there is a logo consisting of four colored squares (red, green, blue, yellow) followed by the text "PDU". Below the logo, a banner displays the text "Total load: 0.0 A , Status: Normal". The main content area is divided into two columns. The left column, titled "Information", contains a list of links: "PDU", "System", "Control", "Outlet", "Configuration", "PDU", "Threshold", "User", "Network", "Mail", and "SNMP". The right column, titled "PDU", shows the total load as "0.0 A Normal". Under the "Configuration" section, there is a "Threshold" table with two rows: "Warning" (12.0 A) and "Overload" (16.0 A).

Threshold	
Warning	12.0 A
Overload	16.0 A

Information: System

Indicate PDU system information.

 PDU		
Total load: 0.0 A , Status: Normal		
Information	Model No.	SWH-1623K-08N1
PDU	Firmware Version	s4.82-091012-1cb08s
System	MAC Address	00:16:18:77:1E:44
Control	System Name	<input type="text" value="PDU"/>
Outlet	System Contact	<input type="text" value="Admin"/>
Configuration	Location	<input type="text" value="Office"/>
PDU		<input type="button" value="Apply"/>
Threshold		
User		
Network		
Mail		
SNMP		

Control: Outlet

Indicate PDU outlet on/off status and control outlet. Display the number of outlet by different model.

Select the outlet by checking the box and then click ON or OFF button to control output power for PDU

ON: Press the icon to turn on the assigned outlets.

OFF: Press the icon to turn off the assigned outlets.

OFF/ON: Press the icon to reboot the assigned outlets.

 PDU			
Total load: 0.0 A , Status: Normal			
Information	PDU	Status	<input type="checkbox"/>
PDU	OutletA	OFF	<input type="checkbox"/>
System	OutletB	OFF	<input type="checkbox"/>
Control	OutletC	ON	<input type="checkbox"/>
Outlet	OutletD	ON	<input type="checkbox"/>
Configuration	OutletE	ON	<input type="checkbox"/>
PDU	OutletF	ON	<input type="checkbox"/>
Threshold	OutletG	ON	<input type="checkbox"/>
User	OutletH	ON	<input type="checkbox"/>
Network	<input type="button" value="ON"/>		<input type="button" value="OFF"/>
Mail	<input type="button" value="OFF/ON"/>		
SNMP			

Configuration: PDU

Set the outlet name and delay time.

Name: Rename the outlet.

ON: Set delay time for power on sequential.

OFF: Set delay time for power off sequential.

Note: The maximum delay time is 255 seconds.

PDU				
Total load: 0.0 A , Status: Normal				
Information	Name	ON Delay(sec)	OFF Delay(sec)	
	OutletA	1	1	<input type="button" value="Apply"/>
	OutletB	2	2	<input type="button" value="Apply"/>
	OutletC	3	3	<input type="button" value="Apply"/>
	OutletD	4	4	<input type="button" value="Apply"/>
	OutletE	5	5	<input type="button" value="Apply"/>
	OutletF	6	6	<input type="button" value="Apply"/>
	OutletG	7	7	<input type="button" value="Apply"/>
	OutletH	8	8	<input type="button" value="Apply"/>
		<input type="button" value="Apply"/>	<input type="button" value="Apply"/>	<input type="button" value="Apply"/>

Configuration: Threshold

Set the warning and overload threshold for PDU.

 **PDU**

Total load: 0.0 A , Status: Normal

Name	Threshold (Amp)	
	Warning	Overload
PDU	12	16

Information

[PDU](#)
[System](#)

Control

[Outlet](#)

Configuration

[PDU](#)
[Threshold](#)
[User](#)
[Network](#)
[Mail](#)
[SNMP](#)

Configuration: User

Change ID and password.

Default ID is snmp and password is 1234.

Note:

Maximum character number of ID and password is 12.

ID and password cannot use special characters.

The screenshot shows a web-based configuration interface for a PDU. The top bar displays the PDU logo and the text "Total load: 0.0 A, Status: Normal". The left sidebar contains a navigation menu with the following items:


- Information**
 - [PDU](#)
 - [System](#)
- Control**
 - [Outlet](#)
- Configuration**
 - [PDU](#)
 - [Threshold](#)
 - User**
 - [Network](#)
 - [Mail](#)
 - [SNMP](#)

The "User" menu item is currently selected, indicated by a blue background. The main content area is titled "Original" and contains two sets of input fields for "ID" and "Password". Below these, another set of fields is labeled "New", also for "ID" and "Password". A "Apply" button is located at the bottom right of the "New" section. The "Original" section is currently empty.

Configuration: Network

PDU network information

Enable DHCP: Change the way to get IP address for PDU.



The screenshot shows a web-based configuration interface for a PDU. The top bar displays the PDU logo and the text "Total load: 0.0 A , Status: Normal". The left sidebar contains a navigation menu with the following items: **Information** (PDU, System), **Control** (Outlet), **Configuration** (PDU, Threshold, User, Network, Mail, SNMP). The **Network** section is currently selected. The main content area is divided into two sections: **IP Address** and **DNS Server IP**. The **IP Address** section contains the following fields: Host Name (DIGIBOARD), IP Address (192.168.2.105), Subnet Mask (255.255.255.0), and Gateway (192.168.2.1). A checked checkbox labeled "Enable DHCP" is also present. The **DNS Server IP** section contains the following fields: Primary DNS IP (192.168.2.1) and Secondary DNS IP (0.0.0.0). A "Apply" button is located at the bottom right of the configuration area.

IP Address	
Host Name	DIGIBOARD
IP Address	192.168.2.105
Subnet Mask	255.255.255.0
Gateway	192.168.2.1
<input checked="" type="checkbox"/> Enable DHCP	
DNS Server IP	
Primary DNS IP	192.168.2.1
Secondary DNS IP	0.0.0.0

Configuration: Mail

When event occurs, PDU can send out email message to pre-defined account.

Email Server: The Email Server only support to be input domain name, not IP address.

Sender's Email: Input the sender email address.

Email Address: Input the recipient email address.

The message in the email:

Indicate OutletA~H-XXXXXXX status in order

X=0 : means the power off.

X=1 : means the power on.

Note: Make sure DNS server can resolve the Email Server's domain name.

The screenshot shows a web-based configuration interface for a PDU. The top bar displays the PDU logo and the text "Total load: 0.0 A, Status: Normal". The left sidebar contains a navigation menu with the following items: Information (PDU, System), Control (Outlet), Configuration (PDU, Threshold, User, Network, Mail, SNMP), and a Mail section which is currently selected. The main content area is titled "Email Setting" and contains the following fields: "Email Server" with the value "mail.your.com", "Sender's Email" with the value "sender@yourcom.com", and a "Recipient's Email Address" field which is empty. Below these fields is an "Apply" button.

Configuration: SNMP

When event occurs, PDU can send out trap message to pre-defined IP address.

Trap Notification: Set receiver IP for trap.

Community: Set SNMP community.

Read Community is public and fixed.

Default Write Community is “public” and can be modified by user.

The screenshot shows a web-based configuration interface for a PDU. The top bar displays the PDU logo and the text "Total load: 0.0 A, Status: Normal". The left sidebar contains a navigation menu with links: PDU, System, Control, Outlet, Configuration, PDU, Threshold, User, Network, Mail, and SNMP. The "SNMP" link is highlighted with a blue background. The main content area is divided into two sections: "Trap Notification" and "Community". The "Trap Notification" section contains a "Receiver IP" field with the value "192.168.0.1" and an "Apply" button. The "Community" section contains two rows: "Read" with the value "public" and "Write" with a field containing "public" and an "Apply" button. Both sections have an "Apply" button at the bottom right.